


COLORATO

www.colorato.net

INSTRUCTION MANUAL OF CITRUS JUICER



MODEL: CLJ-230SHD

Read carefully these instructions before using the
appliance

Contents

- COLORATO recommends safety first 2**
- Important safety for your Citrus juicer 2**
- Exploded view of Spare parts..... 3**
- Technical Parameters 3**
- Before use 4**
- How to operate 4**
- Cleaning 4**

COLORATO recommends safety first


We at COLORATO are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer foremost in mind. In addition, we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions:

Important safeguards for your Citrus Juicer

Before using the electrical appliance, the following basic precautions should always be followed, including the following:

- ◆ Read carefully these instructions and save them for future reference.
- ◆ Before use, check that the voltage of wall outlet corresponds to the one shown on the rating plate.
- ◆ Unplug from the outlet when not in use, before putting on or taking off parts, and before cleaning. Clean motor housing with wet cloth, and wipe dry. Don't dip in water for rinse.
- ◆ The instrument is not intended to be used by persons disabled, with mental aberration or without related experiences and knowledge (including children), except they are supervised and directed by persons who are responsible for their safety to use the product.
- ◆ Close supervision is necessary for any appliance being used by or near children.
- ◆ Do not operate any appliance with a damaged supply cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
- ◆ Don't let supply cord hang over edge of table or worktop, or touch hot surface.
- ◆ If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid hazard.
- ◆ Don't use the appliance if the rotating cone is damaged.
- ◆ Switch off the appliance before changing accessories or approaching parts which move in use.
- ◆ Keep hands, hair, clothing, as well as scraper and other utensils away from juicer during operation to reduce the risk of injury to persons, and damage to the juicer.


Exploded view of Spare parts



Technical Parameters

Model	CLJ-230SHD
Power	230 W
Voltage	220V-50Hz
Speed of motor	980 r/min
Dimensions	28 x 20 x 47 cm



The symbol  on the product means that at the end of its life, the appliance has not to be considered a common waste. It is a special waste and has to be demolished in specific recovery and disposal area, as prescribed by the EC Directive 2002/96/EC(WEEE). By disposing this product correctly, you can avoid negative consequences for the environment and for the human health, due to the presence of potentially dangerous substances in the product.

Before use

1. Read all instructions.
2. Check the voltage of your juicer before plugging it in. Before plugging in, ensure switch is off.
3. Wash all parts and components that are in contact with the juice. Flush them with water and then dry them.

How to operate

1. Cut the fruit in half
2. Place a cup under the spout.
3. Plug in the socket. Switch to the position "1". Align the center of the cut fruit with the top of juicer head and put it down. Press the handle to make the juicer head rotate. Impose even pressure until juice is flowing out (see Fig.2). Then take out the peel and place the other cut fruit. Repeat the above operation. Pay attention to clean the pulp in the filter to avoid overflow of pulp.
4. Switch to the position of "0" when you stop using the appliance. Pull out the plug.
Don't press too tight. If you hear that the motor is rotating more slowly or that it stops, it means that you are pressing too tight. The motor will not become damaged because the thermal protective device turns the motor off in case of over-straining. If this occurs, we advice you to turn the juicer off, using the on/off switch. After a few minutes, the motor will cool off and the juicer can be used again. Make sure to always switch off the juicer after use.

Cleaning

Never use steel wool abrasive cleaning ball or erosive liquid (such as alcohol, gasoline or acetone) to clean the appliance.

1. Always switch off the motor and unplug the juicer.
2. Never immerse the motor housing in water. Wipe it with a damp cloth to clean it and wipe it to dry it.
3. It is easy to detach all parts and components that are in contact with juice, such as juicer head, filter, juice bowl etc, rapidly. Bowl pressing assembly shall be detached in counterclockwise direction holding the handle. It is quite sharp on the bowl edge; pay more attention to avoid scratches to your hands. When assembling the bowl pressing assembly, note to ensure the bowl is always in contact with the bench. Screw up in clockwise direction. Please operate carefully to avoid scratches in your hands.
4. Rinse all parts that are coming into contact with the juice immediately after use.
5. Make sure that you wash all parts that are in contact with the juice before using the appliance for the first time.