


**ASH VACUUM CLEANER
MODEL: CLVC-12S
POWER: 1200 W**

COLORATO

www.colorato.net

INSTRUCTION MANUAL



ATTENTION: THE VACUUM CLEANER VACUUMS ONLY COLD ASHES!
Please read the instruction manual carefully before operation.
Keep this manual safely.

SAFETY DIRECTIONS

IMPORTANT MESSAGE

When using an electrical appliance, basic precaution should always be followed including the following:

READ ALL INSTRUCTION BEFORE USING THIS VACUUM CLEANER

WARNING

To reduce the risk of fire, electric shock, or injury:

Do not use outdoors.

Do not leave vacuum cleaner when plugged in. Turn off the switch and unplug the electrical cord when not in use and before servicing.

Do not allow to be used as a toy. Close attention is necessary when used by or near children.

Use only as this manual described. Use only manufacturer's recommended attachments.

Do not use with damaged power cord or plug.

Do not pull or carry by cord, use a cord as a handle, twisting or pull cord around sharp edges and corners. Do not run this vacuum over cord. Keep the cord away from heated surface.

Do not use extension cords or outlets with inadequate current carrying capacity. Turn off all controls before unplugging.

Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.

Do not handle plug or vacuum cleaner with wet hands or operate without shoes.

Do not put any object into openings. Do not use with the opening blocked. Keep the hose free of dust, lint, hair, and anything that may reduce airflow.

This vacuum cleaner creates suction and contains a revolving brush roll. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts. Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.

Do not use without dust cup or filter in place.

Use extra care when cleaning on stair.

Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.


Store your cleaner indoors in a cool, dry area.

Ensure you turn the unit off at the very minimum every 15 minutes (for 1 minute) to let the motor cool down failure to do so may damage motor.

Do not use this unit for more than 4 hours (including breaks) on any given day.


Technical Specifications:	
Model:	CLVC-12S
Power:	1200 W
Weight:	4.8 kg
Dimensions:	360 x 320 x 440 mm
Noise Level:	76-78 dB(A)
Airflow:	1.6-1.7 m ³ /min
Vacuum pressure:	17-19 KPa
Cord length:	5 m
Metal tank:	20 l
Including accessories:	fire resistant dust bag, filter, crevice tool, hose nozzle with metal

PARTS NAME




OPERATION METHOD

1



Release the lock block to open the up housing, take out accessories.


2



While using sucking function, insert the hose connector into this swivel


OPERATION METHOD

1



Hold the plug and insert into socket

2




Press the switch button to turn on/off the cleaner

TO REPLACE DUST BAG


If the dust barrel is full, please empty it as soon as possible

1




Release the lock block to open the up housing

2



Empty the dust barrel

3



Put back the upper housing,
fasten the locking panel


MAINTENANCE

Warning: When the filters are obviously covered with dust or the suction decreases considerably, please clean it in time, for this can improve the working efficiency and extend the life time of the cleaner.

Never use the machine without filters.

Attention: In case that the vacuum cleaner stops while it is working, you should check to see that the filter of the motor and the filter of the barrel are clean. In case that there is dust or ash accumulated, the thermo fuse of the motor will stop it so that it will be protected from overheating. Once the vacuum cleaner cools down, it will start working again.

1




Remove the filter from the motor by pulling the rubber band.

Attention!

When you are putting the filter back to its place, make sure that it is fastened correctly over the black round groove.

2



Clean it carefully.

3



Air dry.



The symbol  on the product means that at the end of its life, the appliance has not to be considered a common waste. It is a special waste and has to be demolished in specific recovery and disposal area, as prescribed by the EC Directive 2002/96/EC(WEEE). By disposing this product correctly, you can avoid negative consequences for the environment and for the human health, due to the presence of potentially dangerous substances in the product.